

PORTAPACCO SPECIFICO - SPECIFIC HOLDER
 PORTE-PAQUET SPÉCIFIQUE - SPEZIFISCHER TRÄGER
 PORTA-EQUIPAJE ESPECÍFICO

BMW F800R 2009

ISTRUZIONI DI MONTAGGIO - MOUNTING INSTRUCTIONS
 INSTRUCTIONS DE MONTAGE - BAUANLEITUNG - INSTRUCCIONES DE MONTAJE

1



SUPPORTO
 SUPPORT
 SUPPORT
 HALTERUNG
 SOPORTE

Q.TY n.2(Dx-Sx)

2



SUPPORTO
 SUPPORT
 SUPPORT
 HALTERUNG
 SOPORTE

Q.TY n.1

3



VITE TEF M8x70mm
 SCREW
 VIS
 SCHRAUBE
 TORNILLO

Q.TY n.2

4



VITE TBEI M8x65mm
 SCREW
 VIS
 SCHRAUBE
 TORNILLO

Q.TY n.2

5



VITE TSCEI M6x20mm
 SCREW
 VIS
 SCHRAUBE
 TORNILLO

Q.TY n.4

6



DADO A.B. M6
 FLANGIATO
 BOLT M6
 ECRLOU M6
 MUTTER M6
 TUERCA M6

Q.TY n.4

7



DISTANZIALE Ø18x40mm
 Foro Ø8,5mm, V490
 SPACER
 ENTRETROISE
 DISTANZSTÜCK
 DISTANCIADOR

Q.TY n.2

8



DISTANZIALE Ø18x18mm
 Foro Ø8mm, V545
 SPACER
 ENTRETROISE
 DISTANZSTÜCK
 DISTANCIADOR

Q.TY n.2

9



RONDELLA Ø8x14mm
 WASHER Ø8x14mm
 RONDELLE Ø8x14mm
 SCHEIBE Ø8x14mm
 ARANDELA Ø8x14mm

Q.TY n.2

ATTENZIONE: CARICO MASSIMO 6Kg
WARNING: MAX LOAD, 6Kg.
ATTENTION: CHARGE MAXIMUM, 6Kg.
ACHTUNG: MAX, 6Kg.
¡ATENCIÓN: CARGA MÁXIMA, 6Kg.

NON PERMETTE IL MONTAGGIO DI UN KIT LUCI STOP E/O DISPOSITIVO PER L'APERTURA AUTOMATICA.
 IT DOES NOT ALLOW THE INSTALLATION OF A STOP LIGHT KIT AND/OR DEVICE FOR AUTOMATIC OPENING
 IL NE PERMET PAS L'INSTALLATION D'UN KIT FEU STOP ET/OU DISPOSITIF D'OUVERTURE AUTOMATIQUE
 ES ERLAUBT NICHT DIE INSTALLATION EINER AMPEL KIT UND/ODER EINRICHTUNGEN ZUR AUTOMATISCHEN ÖFFNUNG
 NO PERMITE LA INSTALACION DE UN KIT DE LUZ DE FRENO Y/O DISPOSITIVOS DE APERTURA AUTOMÁTICA

